

Milestone 3 (Modulation/Demodulation)

Due Date : 5th June 11:59 pm.

Version 1: Modulation-Demodulation

UPDATES

- DEMODULATION: Since we are doing quadrature demodulation, the multiplication with the complex exponential gives us $I[n] + jQ[n]$. Hence, after the low pass filtering, we need to take the absolute value of the output to calculate the actual demodulated samples (refer slides 24 and 25 [here](#)).

STARTER CODE

Starter Code can be downloaded here : [\[.zip\]](#)

GOAL

- The goal for this version of the milestone is to build the MODULATE, DEMODULATE and DETECT_THRESHOLD blocks (ref: [Overview](#)). You'll implement these blocks in `receiver_mil3.py` and `common_txrx_mil3.py`.
- Once you are done, your code should work just like the audiocom demo. That is, you should be able to:
 - Send monotone using:


```
python sendrecv.py -m 100 -c 1000 -s 256 -q 200
```
 - Send a text/image using:



```
python sendrecv.py -f testfiles/<filename> -c 1000 -s 256 -q 200
```
- Also, if you feed the transmitted samples directly to the receiver (i.e., without introducing the channel) in `sendrecv.py`, you should see no bit errors.
 - You can do this by modifying the line "`demod_samples= r.demodulate(samples_rx)`" to "`demod_samples = r.demodulate(mod_samples)`"

common_txrx_mil3.py

In this file, you will implement the following functions :


- `modulate`: modulate the samples onto a carrier signal of a given carrier frequency; the resulting modulated samples can be played on the speaker
 - Input : carrier frequency, sample rate (number of samples transmitted by the speaker per second), raw samples (before modulation)
 - Output : modulated samples for the speaker

The modulated samples can be generated from the raw samples by multiplying with a local carrier, as shown below.



- `demodulate`: demodulate the audio signal samples with the given carrier frequency
 - Input: carrier frequency, sample rate (number of samples captured by the microphone per second), received samples from the microphone
 - Output: demodulated samples

The demodulated samples can be obtained from the received samples using the following two-steps (ref: quadrature demodulation, [here](#)).



Low Pass Filter

In frequency domain, this low pass filter has a frequency response given by

in frequency-domain, this low pass filter has a frequency response given by

$$H(\Omega) = \begin{cases} 1 & |\Omega| \leq \Omega_c \\ 0 & \text{otherwise} \end{cases}$$

You need to implement this filter in time-domain, with the cut off frequency at $\frac{1}{2}2\pi\frac{f_c}{f_s}$. The corresponding unit sample response is

$$h[n] = \begin{cases} \frac{\sin(\Omega_c n)}{\pi n} & n = -L, \dots, -1, 1, \dots, L \\ \frac{\Omega_c}{\pi} & n = 0 \end{cases}$$

This is a linear, time-invariant (though non-causal) system, so you need to convolve the input to the low pass filter with the above $h[n]$ to get the demodulated samples. In other words, if $r[n]$ are the received samples, then

$$\text{demodsample}[n] = r[n]e^{j2\pi f_c n / f_s} * h[n]$$

You may choose $L = 50$ (i.e. filter length = 101) for the project.

NOTE : Since we are doing quadrature demodulation, the multiplication with the complex exponential gives us $I[n] + jQ[n]$. Hence, after the low pass filtering, we need to take the absolute value of the output to calculate the actual demodulated samples (refer slides 24 and 25 [here](#)).

receiver_mil3.py

In this file, you'll implement the following module.

- `detect_threshold`: computes the centers of the two clusters (corresponding to 0s and 1s) in the demodulated samples, and also the threshold.
 - Input : demodulated samples
 - Output : `one` (center of the 1s cluster), `zero` (center of the 0s cluster), `thresh = (one+zero)/2`

This function performs clustering as mentioned in the Primer [here](#). You need to implement the 2-means clustering algorithm (you may search online for details of the algorithm, for e.g. [here](#)).

SUBMISSION INSTRUCTIONS

1. Login to coursework.stanford.edu using your SUNet ID.
2. Click on *Sp13-ENGR-40N-01* in the top menu to enter the ENGR 40N website on Coursework.
3. Click on *Drop Box* in the left menu to access your online drop box for this course.
4. Upload your files: `receiver_mil3.py`, `common_txrx_mil3.py`. Do NOT rename the files, do NOT create sub-folders (upload the two files into your main drop box folder for the course)
5. *If you are implementing anything special or will also submit Milestone 3 - Source and Channel Coding, place a `README.txt` that describes what you implemented.*

As always, if you encounter any problem, post on [Piazza](#)!

Page generated 2013-05-12 11:39:38 PDT, by jemdoc.